








246-000002



Screw  X24	<b>A</b> <b>Ø4*50</b>	Lock bar  X1	Screw  X34	<b>F</b> <b>Ø3.5*14</b>	<b>K</b>	
Wood Minifix  X26	<b>B</b>	Drawer rail  X2	Handle  X2	<b>G</b>	<b>L</b>	
Minifix Screw  X40	<b>C</b>	Screw  X8	<b>H</b> <b>Ø4*30</b>	Handle screw  X4	<b>M</b> <b>M4*18</b>	
Minifix  X40	<b>D</b>	Lock  C1	<b>I</b>			
Wire box  X2	<b>E</b>	Lock metal fix  X2	<b>J</b>			<p>( 1800×900×760 )</p>

**Ø4\*50** STEP:1

To fix the panel 1 on panel 2 and 3

X12


A




X8

B

To fix the panel 4 on panel 2 and 3




**STEP:2** To fix the minifix screw C on both legs panel ,then to fix front panel 5




X2

B





X4

C




X4

D




**STEP:3**


To fix the minifix screw C on panel 6,  
then to fix the top panel on legs panel





X4 C



X4 D



X2 E




**Ø4\*50** STEP:4

X12




A

To fix the panel 7 on panel 8 and 9




X11




B

To fix the panel 10 on panel 8 and 9




X6



C

To fix the panel 11,12 and 13













X6














D

To fix the panel 14



 <b>X5</b>	<p><b>STEP:5</b> To fix the bottom support panel 15 and one side leg panel</p> 	<p>To fix the another side leg panel</p> 
 <b>X18</b>		<p>To fix the side table top panel 16 finally</p> 
 <b>X18</b>	 <b>D</b> <b>X1</b>	<p>To fix the lock bar F</p> 
 <b>X20</b>	 <b>K</b> <b>X2</b>	<p>To fix the both side rail G</p> 

 <b>C</b> X4	 <b>J</b> X2	<b>STEP:6</b>  17 18 19 <b>Cx4</b> <b>Dx4</b> <p>To fix the panel 17,18,19</p>	 22 23 24 <b>Cx4</b> <b>Dx4</b> <p>To fix the fix 22,23,24</p>
 <b>D</b> X4	 <b>K</b> X10	<p><b>Ø3.5*14</b></p>	 20 21 <b>Hx4</b> <p>To put the panel 20 inside and fix the panel 21</p>
 <b>G</b> X2	 <b>L</b> X2	<p><b>Ø4*30</b></p>	 20 25 <b>Hx4</b> <p>To put the panel 20 inside and fix the panel 25</p>
 <b>H</b> X8	 <b>M</b> X4	<p><b>M4*18</b></p>	 <b>Mx2</b> <b>Jx1</b> <b>Kx2</b> <b>Gx2</b> <b>Ix1</b> <b>Kx4</b> <b>Gx2</b> <b>Jx1</b> <b>Kx2</b> <p>To fix the both side rail G and lock I ,lock metal fix J and handle L</p>
 <b>I</b> C1			 <p><b>FINISH</b></p> <p>To use screw K to fix bottom panel 20 four side more tough</p>